

# Chapter 3

# Basics Semiconductor Devices and Processing

Hong Xiao, Ph. D.

[www2.austin.cc.tx.us/HongXiao/Book.htm](http://www2.austin.cc.tx.us/HongXiao/Book.htm)

# Objectives

- Identify at least two semiconductor materials from the periodic table of elements
- List n-type and p-type dopants
- Describe a diode and a MOS transistor
- List three kinds of chips made in the semiconductor industry
- List at least four basic processes required for a chip manufacturing

# Topics

- What is semiconductor
- Basic semiconductor devices
- Basics of IC processing

# What is Semiconductor

- Conductivity between conductor and insulator
- Conductivity can be controlled by dopant
- Silicon and germanium
- Compound semiconductors
  - SiGe, SiC
  - GaAs, InP, etc.

# Periodic Table of the Elements

1																	2		
1	<b>H</b>																	<b>He</b>	
2	3	4																	10
	<b>Li</b>	<b>Be</b>																	<b>Ne</b>
3	11	12										13	14	15	16	17	18		
	<b>Na</b>	<b>Mg</b>	<b>Al</b>	<b>Si</b>	<b>P</b>	<b>S</b>	<b>Cl</b>	<b>Ar</b>											
4	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	
	<b>K</b>	<b>Ca</b>	<b>Sc</b>	<b>Ti</b>	<b>V</b>	<b>Cr</b>	<b>Mn</b>	<b>Fe</b>	<b>Co</b>	<b>Ni</b>	<b>Cu</b>	<b>Zn</b>	<b>Ga</b>	<b>Ge</b>	<b>As</b>	<b>Se</b>	<b>Br</b>	<b>Kr</b>	
5	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	
	<b>Rb</b>	<b>Sr</b>	<b>Y</b>	<b>Zr</b>	<b>Nb</b>	<b>Mo</b>	<b>Tc</b>	<b>Ru</b>	<b>Rh</b>	<b>Pd</b>	<b>Ag</b>	<b>Cd</b>	<b>In</b>	<b>Sn</b>	<b>Sb</b>	<b>Te</b>	<b>I</b>	<b>Xe</b>	
6	55	56	57	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	
	<b>Cs</b>	<b>Ba</b>	<b>*La</b>	<b>Hf</b>	<b>Ta</b>	<b>W</b>	<b>Re</b>	<b>Os</b>	<b>Ir</b>	<b>Pt</b>	<b>Au</b>	<b>Hg</b>	<b>Tl</b>	<b>Pb</b>	<b>Bi</b>	<b>Po</b>	<b>At</b>	<b>Rn</b>	
7	87	88	89	104	105	106	107	108	109	110	111	112	113						
	<b>Fr</b>	<b>Ra</b>	<b>+Ac</b>	<b>Rf</b>	<b>Ha</b>	<b>Sg</b>	<b>Ns</b>	<b>Hs</b>	<b>Mt</b>	<b>110</b>	<b>111</b>	<b>112</b>	<b>113</b>						

\* Lanthanide Series

58	59	60	61	62	63	64	65	66	67	68	69	70	71
<b>Ce</b>	<b>Pr</b>	<b>Nd</b>	<b>Pm</b>	<b>Sm</b>	<b>Eu</b>	<b>Gd</b>	<b>Tb</b>	<b>Dy</b>	<b>Ho</b>	<b>Er</b>	<b>Tm</b>	<b>Yb</b>	<b>Lu</b>

+ Actinide Series

90	91	92	93	94	95	96	97	98	99	100	101	102	103
<b>Th</b>	<b>Pa</b>	<b>U</b>	<b>Np</b>	<b>Pu</b>	<b>Am</b>	<b>Cm</b>	<b>Bk</b>	<b>Cf</b>	<b>Es</b>	<b>Fm</b>	<b>Md</b>	<b>No</b>	<b>Lr</b>

# Semiconductor Substrate and Dopants


Substrate

P-type  
Dopant


IIIA	IVA	VA	VIA	VIIA
5 B	6 C	7 N	8 O	9 F
13 Al	14 Si	15 P	16 S	17 Cl
31 Ga	32 Ge	33 As	34 Se	35 Br

N-type Dopants

# Orbital and Energy Band Structure of an Atom





# Band Gap and Resistivity






# Crystal Structure of Single Crystal Silicon




# Why Silicon

- Abundant, inexpensive
- Thermal stability
- Silicon dioxide is a strong dielectric and relatively easy to form
- Silicon dioxide can be used as diffusion doping mask


# N-type (Arsenic) Doped Silicon and Its Donor Energy Band




# P-type (Boron) Doped Silicon and Its Donor Energy Band



# Illustration of Hole Movement



# Dopant Concentration and Resistivity



# Dopant Concentration and Resistivity


- Higher dopant concentration, more carriers (electrons or holes)
- Higher conductivity, lower resistivity
- Electrons move faster than holes
- N-type silicon has lower resistivity than p-type silicon at the same dopant concentration

# Basic Devices

- Resistor
- Capacitor
- Diode
- Bipolar Transistor
- MOS Transistor



# Resistor



$$R = \rho \frac{l}{wh}$$



$\rho$ : Resistivity



# Resistor

- Resistors are made by doped silicon or polysilicon on an IC chip
- Resistance is determined by length, line width, height, and dopant concentration

# Capacitors




$$C = \kappa \frac{hl}{d}$$

$\kappa$ : Dielectric Constant


# Capacitors

- Charge storage device
- Memory Devices, esp. DRAM
- Challenge: reduce capacitor size while keeping the capacitance
- High- $\kappa$  dielectric materials

# Capacitors




Parallel plate



Stacked

Deep Trench


# Metal Interconnection and RC Delay



# Diode

- P-N Junction
- Allows electric current go through only when it is positively biased.

# Diode



•  $V_1 > V_2$ ,  $\xrightarrow{\text{current}}$

•  $P_1 > P_2$ ,  $\xrightarrow{\text{current}}$



•  $V_1 < V_2$ , no current

•  $P_1 < P_2$ , no current



# Figure 3.14

Transition region




# Intrinsic Potential

$$V_0 = \frac{kT}{q} \ln \frac{N_a N_d}{n_i^2}$$

- For silicon  $V_0 \sim 0.7$  V


# I-V Curve of Diode




# Bipolar Transistor

- PNP or NPN
- Switch
- Amplifier
- Analog circuit
- Fast, high power device


# NPN and PNP Transistors



# NPN Bipolar Transistor



# Sidewall Base Contact NPN Bipolar Transistor




# MOS Transistor

- Metal-oxide-semiconductor
- Also called MOSFET (MOS Field Effect Transistor)
- Simple, symmetric structure
- Switch, good for digital, logic circuit
- Most commonly used devices in the semiconductor industry




# NMOS Device


## Basic Structure




# NMOS Device



# PMOS Device



# MOSFET



# MOSFET and Drinking Fountain

## MOSFET

- Source, drain, gate
- Source/drain biased
- Voltage on gate to turn-on
- Current flow between source and drain

## Drinking Fountain

- Source, drain, gate valve
- Pressurized source
- Pressure on gate (button) to turn-on
- Current flow between source and drain

# Basic Circuits

- Bipolar
- PMOS
- NMOS
- **CMOS**
- BiCMOS

# Devices with Different Substrates

Silicon

- Bipolar
  - MOSFET
  - BiCMOS
- Dominate  
IC industry


Germanium

- Bipolar: high speed devices

Compound

- GaAs: up to 20 GHz device
- Light emission diode (LED)

# Market of Semiconductor Products





# Bipolar IC

- Earliest IC chip
- 1961, four bipolar transistors, \$150.00
- Market share reducing rapidly
- Still used for analog systems and power devices
- TV, VCR, Cellar phone, etc.

# PMOS

- First MOS field effect transistor, 1960
- Used for digital logic devices in the 1960s
- Replaced by NMOS after the mid-1970s


# NMOS

- Faster than PMOS
- Used for digital logic devices in 1970s and 1980s
- Electronic watches and hand-hold calculators
- Replaced by CMOS after the 1980s


# CMOS

- Most commonly used circuit in IC chip since 1980s
- Low power consumption
- High temperature stability
- High noise immunity
- Symmetric design

# CMOS Inverter



# CMOS IC



# BiCMOS

- Combination of CMOS and bipolar circuits
- Mainly in 1990s
- CMOS as logic circuit
- Bipolar for input/output
- Faster than CMOS
- Higher power consumption
- Likely will have problem when power supply voltage dropping below one volt

# IC Chips

- Memory
- Microprocessor
- Application specific IC (ASIC)




# Memory Chips

- Devices store data in the form of electric charge
- Volatile memory
  - Dynamic random access memory (DRAM)
  - Static random access memory (SRAM)
- Non-volatile memory
  - Erasable programmable read only memory (EPROM)
  - FLASH

# DRAM

- Major component of computer and other electronic instruments for data storage
- Main driving force of IC processing development
- One transistor, one capacitor

# Basic DRAM Memory Cell




# SRAM

- Fast memory application such as computer cache memory to store commonly used instructions
- Unit memory cell consists of six transistors
- Much faster than DRAM
- More complicated processing, more expensive


# EPROM

- Non-volatile memory
- Keeping data ever without power supply
- Computer bios memory which keeps boot up instructions
- Floating gate
- UV light memory erase


# EPRM



# EPRM Programming




# EPRM Programming






# IC Fabrication Processes




# Basic Bipolar Process Steps

- Buried layer doping
- Epitaxial silicon growth
- Isolation and transistor doping
- Interconnection
- Passivation


# Buried Layer Implantation




# Epitaxy Grow




# Isolation Implantation




# Emitter/Collector and Base Implantation



# Metal Etch



# Passivation Oxide Deposition





# MOSFET

- Good for digital electronics
- Major driving forces:
  - Watches
  - Calculators
  - PC
  - Internet
  - Telecommunication

# 1960s: PMOS Process


- Bipolar dominated
- First MOSFET made in Bell Labs
- Silicon substrate
- Diffusion for doping
  - Boron diffuses faster in silicon
  - PMOS

# PMOS Process Sequence (1960s)


Wafer clean	(R)	Etch oxide	(R)
Field oxidation	(A)	Strip photo resist	(R)
<b>Mask 1. (Source/Drain)</b>	(P)	Al deposition	(A)
Etch oxide	(R)	<b>Mask 4. (Metal)</b>	(P)
Strip photo resist/Clean	(R)	Etch Aluminum	(R)
S/D diffusion (B)/Oxidation	(A)	Strip photo resist	(R)
<b>Mask 2. (Gate)</b>	(P)	Metal Anneal	(H)
Etch oxide	(R)	CVD oxide	(A)
Strip photo resist/Clean	(R)	<b>Mask 5. (Bonding pad)</b>	(P)
Gate oxidation	(A)	Etch oxide	(R)
<b>Mask 3. (Contact)</b>	(P)		

Hong Xiao, Ph. D.


# Wafer clean, field oxidation, and photoresist coating




# Photolithography and etch




# Source/drain doping and gate oxidation



# Contact, Metallization, and Passivation



# Illustration of a PMOS






# NMOS Process after mid-1970s

- Doping: ion implantation replaced diffusion
- NMOS replaced PMOS
  - NMOS is faster than PMOS
- Self-aligned source/drain
- Main driving force: watches and calculators

# Self-aligned S/D Implantation



# NMOS Process Sequence (1970s)

Wafer clean

Grow field oxide

**Mask 1.** Active Area

Etch oxide

Strip photo resist/Clean

Grow gate oxide

Deposit polysilicon

**Mask 2.** Gate

Etch polysilicon

Strip photo resist/Clean

S/D and poly dope implant

Anneal and poly reoxidation

CVD USG/PSG

PSG reflow

**Mask 3.** Contact

Etch PSG/USG

Strip photo resist/Clean

Al deposition

**Mask 4.** Metal

Etch Aluminum

Strip photo resist

Metal anneal


CVD oxide

**Mask 5.** Bonding pad


Etch oxide

*Test and packaging*

# NMOS Process Sequence



# NMOS Process Sequence




# CMOS

- In the 1980s MOSFET IC surpassed bipolar
  - LCD replaced LED
  - Power consumption of circuit
  - CMOS replaced NMOS
  - Still dominates the IC market
- 
- Backbone of information revolution

# Advantages of CMOS


- Low power consumption
- High temperature stability
- High noise immunity

# CMOS Inverter, Its Logic Symbol and Logic Table






# CMOS Chip with 2 Metal Layers



# CMOS Chip with 4 Metal Layers



Hong Xiao, Ph. D.

# Summary

- Semiconductors are the materials with conductivity between conductor and insulator
- Its conductivity can be controlled by dopant concentration and applied voltage
- Silicon, germanium, and gallium arsenate
- Silicon most popular: abundant and stable oxide

# Summary

- Boron doped semiconductor is p-type, majority carriers are holes
- P, As, or Sb doped semiconductor is n-type, the majority carriers are electrons
- Higher dopant concentration, lower resistivity
- At the same dopant concentration, n-type has lower resistivity than p-type

# Summary

- $R = \rho l/A$
- $C = \kappa A/d$
- Capacitors are mainly used in DRAM
- Bipolar transistors can amplify electric signal, mainly used for analog systems
- MOSFET electric controlled switch, mainly used for digital systems

# Summary

- MOSFETs dominated IC industry since 1980s
- Three kinds IC chips microprocessor, memory, and ASIC
- Advantages of CMOS: low power, high temperature stability, high noise immunity, and clocking simplicity

# Summary

- The basic CMOS process steps are transistor making (front-end) and interconnection/passivation (back-end)
- The most basic semiconductor processes are adding, removing, heating, and patterning processes.